



Iron SFV badge

Stable base

Use a stable base so that you can apply some pressure to the badge. (e.g. cover a stable table with a bath towel).


Heat up the iron

Set the iron to level 2 and let it heat up.



Iron on badge

Place the badge in the correct position (left breast pocket when the referee is wearing the jersey – heart side) and cover with a sheet of clean paper (baking paper) (serves as a protective layer between the iron and the badge).



Use the preheated iron to "press" the badge on for approx. 30 seconds. Apply medium pressure to the badge (one arm is sufficient).

Allow the badge to cool before testing the hold of the badge.

Repeat the process if necessary.